

FITTING GUIDE



Product is to be installed in accordance with AS:1884: 2012 and AS/NZS 2455.

Subfloor

All surfaces to be bonded to should be dry, smooth, absorbent, structurally sound and clean. Subfloors should be free from wax, grease, polish, paint, previously used adhesive and hydrostatic pressure. The minimum subfloor temperature before commencing works should be 10°C.

Adhesives

Adhesive Type is subject to application. For application instructions and direction of use please refer to the Product Data Sheet from the manufacturer.

Confirm appropriate adhesives for use between Advantage 3 and the floor covering with the floor covering and adhesive manufacturers.

For a list of approved adhesives for Advantage 3 to the subfloor please contact your a Dunlop Sales Representative.

Preparation

Advantage 3 should always be stored in a dry area at a consistent temperature – **Between 10°C and 35°C.**

Product should be acclimatised on site along with the floor covering product according to manufacturer's instructions.

Installation | Floating

The underlay roll should be laid perpendicular to the direction of the flooring being installed onto it.

Trim the underlay to the required dimensions, ensuring sufficient clearance to perimeter walls and fixtures.

All adjoining edges of the underlay rolls must be butted tightly and where applicable an approved joining tape applied to hold the underlay in place.

Installation | Glued

The underlay roll should be laid perpendicular to the direction of the flooring being installed onto it.

Trim the underlay to the required dimensions, ensuring sufficient clearance to perimeter walls and fixtures.

Dry lay your underlay into the installation space to confirm that the underlay has been cut to correct dimensions.

Then roll/fold underlay back to the middle of the room to expose the subfloor and apply the adhesive as per the adhesive manufacturer's instructions.

Lay the underlay back into the adhesive bed and roll carefully with a **minimum 45kg steel roller.**

Check for excess adhesive oozing out between the edges of underlay rolls and wipe up immediately.

Roll/fold the other half of the underlay back and repeat the above procedure.

Installation of Flooring

The installation of the floor covering must be undertaken in accordance with both the floor covering and adhesive manufacturer's recommendations.

Ensure that the floor covering is fit for use with Dunlop Advantage 3 underlay.

Read all installation, care and maintenance guidelines provided by the floor covering and adhesive manufacturers and observe their recommendations.