



FITTING GUIDE



PLEASE READ BEFORE INSTALLATION



Dunlop Flooring only warrants product that is installed in accordance with **Australian and New Zealand Standards 2455.1:2007 Part 1 (Textile Floor Coverings – Installation Practice)**

Section 3.7 – Method of Installation when Using the Dual Bond System

(e) Bond the underlay firmly to the subfloor in accordance with the manufacturer’s instructions with an adhesive approved by the underlay manufacturer.

Section 3.6.3 – Laying Procedure

(g) Apply the adhesive in accordance with the adhesive and the textile floor covering manufacturer’s directions.

PLEASE NOTE:

The underlay is to be fitted with the black scrim side facing upwards.

Due to the possible shrinkage of some types of carpets, it is mandatory that smooth edge or a carpet gripper system be used with all installations regardless of them being conventional or dual bond. In addition, you **MUST** lay the underlay with tight butt joints secured by applying a quality joining tape with a minimum width of 50mm. Run the tape continuously down the butted underlay seams and joints. On timber floors use stapling or some other method of fixing to prevent movement.

DUNLOP DUAL BOND CARPET UNDERLAY TO

SUBFLOOR	SMOOTH BACKED CARPETS	TEXTURED BACK and ALL WOVEN BACK CARPETS
1.6 x 1.6 x 1.6mm	2.4 x 2.4 x 2.4mm	3.2 x 1.6 x 3.2mm
(V1 Notch Trowel)	(V2 Notch Trowel)	(V3 Notch Trowel)

ADHESIVES

Please contact your preferred adhesive manufacturer to identify the most appropriate adhesive for your installation purposes.

